HTTP, DNS and DHCP

Objective

To configure and understand the HTTP, DNS and DHCP service.


Devices Used

S. No.	Device	Model	Quantity
1.	PC	PC	4
2.	Switch	2960	2
3.	Router	4331	1
4.	Cable	Straight Through	9
5.	Server	PT Server	3

IP Addressing


Device	Interface	IP	Subnet Mask	DNS Server	Default
					gateway
Router 0	Gig 0/0/0	192.168.100.1	255.255.255.0	-	-
Router 0	Gig 0/0/1	192.168.200.1	255.255.255.0	-	-
Server 0	NIC	192.168.200.20	255.255.255.0	192.168.200.30	192.168.200.1
Server 1	NIC	192.168.200.30	255.255.255.0	192.168.200.30	192.168.200.1
Server 2	NIC	192.168.200.40	255.255.255.0	192.168.200.30	192.168.200.1

Topology




Procedure


- 1. Create the topology as shown above
- 2. Assign the IP address to each server as shown in IP table.
- 3. Set up the DHCP Server



4. Set up the DNS server



5. Setup the Web server



6. Setup the router interface

Router>enable

Router#configure terminal

Router(config)#interface GigabitEthernet0/0/0

Router(config-if)#ip address 192.168.100.1 255.255.255.0

Router(config-if)#no shutdown

Router(config-if)#exit

Router(config)#interface GigabitEthernet0/0/1

Router(config-if)#ip address 192.168.200.1 255.255.255.0

Router(config-if)#no shutdown


Router(config-if)#exit

To forward broadcast message to DHCP server:


Router(config)#interface gig 0/0/0

Router(config-if)#ip helper-address 192.168.20.2

7. Get the IP in each PC by selecting DHCP Option as: click on PC-> click on desktop tab and the select the DHCP then DHCP request sent to the DHCP server and server will assign the IP



Verification



Click in any one PC select desktop tab select web browser and then enter subodhstha.com.np then you will get the following response from the Web server after resolving domain name tek.com.np into ip address 192.168.200.40 by the DNS server.